Protective Panel Measuring Sheet

Height:



																								\pm			\vdash
												_							- 1				_	_			1
																							- 1		1	1 1	 \vdash
									_				+		_	+						-		+	+-		┢
									- 1			_	+		_	+						_	_	+	+		\vdash
							1 1		_			_	+		_	+			_			-	_	+	+		\vdash
						1									_										+		
			-	- 1																				\top	1		Т
		1 1																							1		
																											_
																											_
				_											_	1		_				_		_			▙
	+ +			_																		_		_			⊢
		+ +		_					_			_	+		_			_	_		+	-	_	+	+		⊢
		+		_								_			-	-		-			+	-	-	+	+		⊢
	+ +	+	-	-			+		+			+	+		+	+		_	+		+		-	+	+-		⊬
				+					+			+			+	1		-	+			_	-	+	+-		⊢
	1 1																				1 1	-		+	+		H
																								+			H
																									1		T
																											T
																						_					▙
	1	1		_					_				_		_	-		_	_	-	1	_		+			┡
	+	+ 1		_					_			_			_	-		_	_		+		_	_	+		⊢
	+	+ +		_			+	_	_			_	+	\vdash	_	+		-	_	+	+	-	-	+	+		⊢
	+			-			+		_			-	+	\vdash	+	+		_	_	+	+	-+	-	+	+-		⊢
				+				-	+			_						+	+			_	-	+	+		H
																								+	-		H
																								_			H
																								\top	+		H
																											T
		$oxed{\Box}$			Ш		\Box							Ш						\perp	\sqcup				╨		Ľ
	$\perp \perp$	$\perp \perp \downarrow$			\perp		$\perp \perp$					\perp		Ш		1				\perp	$\perp \perp$				₩		L
	+	+			\vdash		+		_	1	\vdash	\perp	+	\square	 \perp	1	$\vdash \vdash$	_	_	+	\vdash	\perp	_	+	┼		▙

Notes:

Longth:

Reminders:

- *Measurements <u>must</u> be taken off the actual wall, not existing pads!
- *Indicate the height of the panels and the total length of the wall.
- *Sketch al cutouts, openings, beans and corners in their approximate position. See example.